

This document is currently under revision by the European Commission (EC) and has not yet been validated or approved by the EC. The content provided herein is subject to change, and the information presented may not represent the final position or official stance of the EC.

This document is being shared for informational purposes only and is not to be considered an official or authoritative source of information from the European Commission. Any decisions, actions, or interpretations based on the content of this document should be taken with caution, as the content may be subject to modification or revision by the EC.

The EC accepts no liability for any inaccuracies, errors, or omissions in this document, and any reliance on its content is at the user's own risk. It is recommended to verify the information provided in this document with official EC publications or communications before making any decisions or drawing any conclusions based on its content.

Please note that the content in this document may be confidential or sensitive in nature and should be treated as such. Unauthorized dissemination, distribution, or use of this document is strictly prohibited.


By accessing and reviewing this document, you acknowledge and accept the terms of this disclaimer.

# Meeting Concerning The Separation of HTL Products and Analysis

# Separation method and first findings

under revision by the European Commission

# pH and Conductivity of Feed stream, Brine, & HTL product




It is worth mentioning after diluting BL with Flushing water the pH and Conductivity are as follows:

pH: 10,38


Conductivity: 36,5mS/cm

**Top Product:** pH = 8,56 ; Conductivity = 5.46 mS/cm

**Deionized Water :**  
 Black Liquor: pH = 6,52 ;  
 Conductivity = 5,35  $\mu$ S/cm




**Black Liquor:** pH = 13,4 ;  
 Conductivity = 68,9 mS/cm




**Brine:** pH = 9,37 ; Conductivity = 54,7 mS/cm

# HTL Products Separation Process



# Final products after acidification and separation



**Brine before separation:**

pH = 9,37 ;


Conductivity = 54,7 mS/cm

**Brine after separation:**

pH = 3.88

Conductivity = 51.5 mS/cm

**TOC = 10300 mg/L**



**Brine before separation:**

pH = 8,56 ;

Conductivity = 5,46 mS/cm

**Brine before separation:**

pH = 3.4 ;

Conductivity = 5,17 mS/cm


**TOC= 1289 mg/L**

# Elemental Analysis

Sample	C	H	N	S	O	Ash	HHV
Lignin	57	5.21	0.1122	21	34	1.58	29.90184
DBL	32	3	0.0142	0.6824	19	45.04	17.064
Hydrochar from Brine Solids	73.9312	3.3737	0.79743	0	16.6847	5.213	31.81569
Hydrochar Precipitated from Brine	54.853	2.89314	1.18643	0	37.6374	3.43	26.89737
Hydrochar Top Product	76.1597	4.48894	0.81464	0	16.1487	2.388	33.83708
Biocrude Top Product	75.3649	5.93507	0.50289	0.85886	17.3382	0	35.35075
Biocrude from Brine Solids	64.7283	6.46386	0.2978	0	28.5101	0	33.45155
Biocrude Precipitated from Brine	63.586	4.94743	0.47803	3.31839	27.6701	0	31.20564

under revision by the European Commission

# Thermogravimetric Analysis



	Moisture	VM	FC
<b>Biocrude from Top product</b>	2,2	56,61	41,187
<b>Biocrude from Brine solids</b>	3	54,517	42,483
<b>Biocrude precipitated from Brine</b>	2	59.205	38.794

under revision by the European Commission

1	2,5-Furandione, 3-methyl-
2	2-Cyclopenten-1-one, 2,3-dimethyl-
3	1-Ethylpentyl acetate
4	2-Cyclopenten-1-one, 3,4,4-trimethyl-
5	p-Cresol
6	Ethanone, 1-(1-cyclohexen-1-yl)-
7	2-Cyclopenten-1-one, 2,3,4,5-tetramethyl-
8	Ethanone, 1-(3-methylphenyl)-
9	Phenol, 2,3-dimethyl-
10	2-Cyclopenten-1-one, 2,3,4,5-tetramethyl-
11	Phenol, 3-ethyl-
12	1H-Indene, 2,3-dihydro-1,6-dimethyl-
13	Phenol, 3,4-dimethyl-
14	Catechol
15	Benzene, 1-ethyl-4-methoxy-
16	Ethanone, 1-(2,5-dimethylphenyl)-
17	Ethanone, 1-(2,4-dimethylphenyl)-
18	Phenol, 3-ethyl-5-methyl-
19	1,2-Benzenediol, 4-methyl-
20	4-Methoxy-2,6-dimethylphenol
21	1H-Inden-1-one, 2,3-dihydro-
22	1,2-Benzenediol, 4-methyl-
23	1,3-Benzenediol, 2,5-dimethyl-
24	1-Methylindan-2-one
25	Benzene, 1-(1-methylethenyl)-3-(1-methylethyl)-
26	1,3-Benzenediol, 2,5-dimethyl-
27	Phenol, 2-(2-methyl-2-propenyl)-
28	(1-Methylpenta-1,3-dienyl)benzene
29	Ethyl p-hydroxybenzoate
30	7-Methylindan-1-one
31	1,3-Benzenediol, 4,5-dimethyl-
32	Benzene, 1,4-dimethoxy-2-methyl-
33	1,4-Benzenediol, 2,3,5-trimethyl-
34	3-Isopropyl-1,2-benzenediol
35	Benzene, hexamethyl-
36	1,3-Benzenediol, 4-propyl-
37	Benzene, 1-methoxy-4-(1-methyl-2-propenyl)-
38	3-Isopropyl-1,2-benzenediol

39	4-Methoxy-2,6-dimethylphenol
40	1-Naphthalenol
41	1,4-benzenediol, 2-(1-methylpropyl)-
42	4-(Cyclopent-2-en-1-yl)phenol
43	Benzene, 1,3,5-trimethyl-2-(1-methylethenyl)-
44	Benzene, 3-ethyl-1,2,4,5-tetramethyl-
45	1-Hydroxy-1,2,3,4-tetrahydronaphthalene-8-carboxaldehyde
46	1,4-benzenediol, 2-(1-methylpropyl)-
47	2,3-2H-Benzofuran-2-one, 3,3,4,6-tetramethyl-
48	1-Naphthalenol, 2-methyl-
49	1-Methyl-2-naphthol
50	7-Methylnaphthalen-2-ol
51	7-Methyl-1-naphthol
52	1-Naphthalenol, 2-methyl-
53	Benzene, 1,2,3,4-tetramethyl-4-(1-methylethenyl)-
54	1H-Inden-1-one, 2,3-dihydro-3,4,7-trimethyl-
57	1-Naphthol, 6,7-dimethyl-
62	1-Naphthol, 5,7-dimethyl-
64	1-Naphthol, 2,5,8-trimethyl-
66	Chamazulene
67	Naphthalene, 1,6-dimethyl-4-(1-methylethyl)-
68	Benzenamine, 4,4'-methylenebis[2-methyl-
69	5(10H)-Pyrido[3,4-b]quinoline, 7-methoxy-
70	Tetrapentacontane, 1,54-dibromo-
72	17-Pentatriacontene
73	Tetrapentacontane, 1,54-dibromo-
74	Dotriacontyl pentafluoropropionate
75	gamma.-Sitosterol
76	2-Methylhexacosane

40 to 400 °C

1	Propane
2	2-Butene, (E)-
3	2-Hexanone, 5-methyl-
4	1,3-Pentadiene,
4	(E)-
5	1,3-Cyclopentadiene
6	1,3-Cyclohexadiene
7	Benzene
8	Thiophene
9	Toluene
10	Thiophene, 3-methyl-
11	p-Xylene
12	p-Xylene
13	Phosphonic acid, (p-hydroxyphenyl)-
14	Mesitylene
15	Indene
16	Phenol, 2-methyl-
17	Phenol, 2-methyl-
18	2-Methylindene
19	Phenol, 3,4-dimethyl-
20	Naphthalene
21	Phenol, 3,4-dimethyl-
22	Catechol
23	Phenol, 2-ethyl-4-methyl-
24	1,2-Benzenediol, 4-methyl-
25	
26	Naphthalene, 2-methyl-
27	Naphthalene, 2-methyl-
28	4,7-Methano-1H-indene-1,8-dione, 3a,4,7,7a-tetrahydro-
29	Benzene, 2-ethenyl-1,3,5-trimethyl-

400 to 850 °C

1	Dimethyl trisulfide
2	Phenol, 2-methyl-
3	2-Cyclopenten-1-one, 3,4,4-trimethyl-
4	Phenol, 3-methyl-
5	Ethanone, 1-(1-cyclohexen-1-yl)-
6	Phenol, 3,4-dimethyl-
7	Phenol, 3,4-dimethyl-
8	Phenol, 2,5-dimethyl-
9	Phenol, 3,4-dimethyl-
10	Catechol
11	Tetrasulfide, dimethyl
12	Phenol, 3-(1-methylethyl)-
13	Phenol, 2,3,5-trimethyl-
14	Phenol, 2-ethyl-4-methyl-
15	1,3-Cyclopentadiene, 1,2,3,4,5-pentamethyl-
16	Phenol, 3-ethyl-5-methyl-
17	1,2-Benzenediol, 4-methyl-
18	Phenol, 2,3,5-trimethyl-
19	4-Methoxy-2,6-dimethylphenol
20	1,3-Benzenediol, 2-methyl-
21	1,3-Benzenediol, 2,5-dimethyl-
22	Ethyl p-hydroxybenzoate
23	2,3-Dimethylhydroquinone
24	4-Hydroxy-1-indanone
25	2,3-Dimethylhydroquinone
26	1,3-Benzenediol, 4,5-dimethyl-
27	1,4-Benzenediol, 2,5-dimethyl-
28	4-Methoxy-2,6-dimethylphenol
29	1,4-Benzenediol, 2,3,5-trimethyl-
30	4-Methoxy-2,6-dimethylphenol
32	Benzaldehyde, 2,3,4,5-tetramethyl-
33	3-Isopropyl-1,2-benzenediol
34	1,3-Benzenediol, 4-propyl-
35	Benzaldehyde, 2,3,4,5-tetramethyl-
36	3-Isopropyl-1,2-benzenediol
37	Benzofuran, 2,3-dihydro-2,2,4,6-tetramethyl-
38	4-Methoxy-2,6-dimethylphenol
39	1-Naphthalenol
40	2',4'-Dihydroxypropiophenone
41	1,3,5-Cycloheptatriene, 2,5-diethyl-7,7-dimethyl-
42	1H-Inden-1-one, 2,3-dihydro-3,3-dimethyl-
45	2',4'-Dihydroxypropiophenone
47	p-Cymene-2,5-diol
49	Phenol, 2-ethoxy-4-(2-propenyl)-
50	1-Naphthalenol, 2-methyl-

51	1-Methyl-2-naphthol
52	7-Methylnaphthalen-2-ol
61	1-Naphthol, 6,7-dimethyl-
62	1H-Inden-1-one, 2,3-dihydro-7-hydroxy-3-methyl-
63	5-Hydroxy-3-methyl-1-indanone
64	1,5-Naphthalenediol
65	2H-1-Benzopyran-2-one, 3,4-dihydro-4,4-dimethyl-
68	1-Naphthol, 6,7-dimethyl-
70	1H-Inden-1-one, 2,3-dihydro-5-methoxy-
71	Benzofuran, 5-methoxy-6,7-dimethyl-
72	Benzofuran, 2,3-dihydro-2,2,4,6-tetramethyl-
73	1,4-Methanonaphthalene-5,8-diol, 1,2,3,4-tetrahydro-
74	2H-1-benzopyran-2-one, 3,4-dihydro-4,4,6-trimethyl-
76	2,2'-Ethylidenebis(5-methylfuran)
79	3-Methylindene-2-carboxylic acid
85	2H-1-Benzopyran-2-one 3,4-dimethyl-
86	Tetradecanoic acid
89	8-Methoxy-2,2,4-trimethyl-1,2-dihydroquinoline
91	Benzene, 1-(1-cyclohexen-1-yl)-4-methoxy-
94	6-Quinolinecarboxaldehyde, 1,2-dihydro-1,2,2,4-tetramethyl-
95	Thiazolo[4,5-f]quinoline, 7,9-dimethyl-
98	Bis(2-ethylhexyl) phthalate
99	Benzenepropanoic acid, 3,5-bis(1,1-dimethylethyl)-4-hydroxy-, octadecyl ester

40 to 400 °C

1	o-Ethylhydroxylamine
2	Palladium, bis[(1,2,3-eta.)-2-butenyl]-
3	2-Hexanone, 5-methyl-
4	1,3-Pentadiene, (E)-
5	1,3-Cyclopentadiene
6	1-Penten-3-yne
7	2-Butanone
8	1,3-Butadiene, 2,3-dimethyl-
9	1,4-Cyclohexadiene
10	Benzene
11	Thiophene
12	Toluene
13	Thiophene, 3-methyl-
14	p-Xylene
15	Styrene
16	p-Xylene
17	Benzene, 1-ethyl-2-methyl-
18	Mesitylene
19	Phosphonic acid, (p-hydroxyphenyl)-
20	Mesitylene
21	Benzofuran
22	Indene
23	Phenol, 2-methyl-
24	Phenol, 3-methyl-
25	Phenol, 3,4-dimethyl-
26	Benzene, 1-methyl-4-(1-propynyl)-
27	1H-Indene, 1-methyl-
28	Azulene
29	Phenol, 3,4-dimethyl-
30	Phenol, 2,3-dimethyl-
31	Naphthalene
32	Phenol, 3,4-dimethyl-
33	Catechol
34	Phenol, 2,4,6-trimethyl-
35	4-Vinylphenol
36	Phenol, 2-ethyl-4-methyl-
37	1,2-Benzenediol, 4-methyl-
38	Benzocycloheptatriene
39	Phenol, 2,4,6-trimethyl-
40	1,2-Benzenediol, 4-methyl-
41	Naphthalene, 2-methyl-
42	Naphthalene, 2-methyl-
43	Hydroxychavicol
44	5-Methyl-1-phenyl-1H-tetrazole
45	Naphthalene, 1,7-dimethyl-
46	Naphthalene, 1,4-dimethyl-

47	Biphenyl
48	Naphthalene, 2,3-dimethyl-
49	Biphenylene
50	Cyclopropane, 1-(1-hydroxyethyl)-2-methylene-1-phenyl-
51	Carbaril
52	1-Naphthalenol
53	Naphthalene, 1,4,6-trimethyl-
55	Fluorene
58	7-Methylnaphthalen-2-ol
62	1-Naphthol, 6,7-dimethyl-
65	Phenanthrene
66	Phenol, 2-(phenylmethyl)-
67	4,6,8-Trimethyl-1-azulenecarbaldehyde
68	4,6,8-Trimethyl-1-azulenecarbaldehyde
69	2-Hydroxyfluorene
70	2-Hydroxyfluorene
72	Naphtho[2,1-b]furan, 1,2-dimethyl-
74	Phenol, 4,4'-methylenebis-
77	3-Phenanthrol
80	Pyrene, 1,2,3,6,7,8-hexahydro-
82	.beta.-Carboline, 8-methoxy-1-methyl-
84	.beta.-Carboline, 8-methoxy-1-methyl-
86	Benzo[b]naphtho[2,3-d]furan
92	Indeno[2,1-b]chromene,

400 to 850 °C

# Pyro-GC-MS Qualitative Analysis of Top Product

1	2-Cyclopenten-1-one, 3,4,4-trimethyl-
2	2-Cyclopenten-1-one, 2,3,4,5-tetramethyl-
3	Phenol, 2,6-dimethyl-
4	Phenol, 2,4-dimethyl-
5	3,4,5,6,7,8-Hexahydro-2H-chromene
6	Phenol, 2,4,6-trimethyl-
7	Catechol
8	Ethanone, 1-(2,4-dimethylphenyl)-
9	1H-Indene, 1,3-dimethyl-
10	1,2-Benzenediol, 4-methyl-
11	1H-Inden-1-one, 2,3-dihydro-
12	1,2-Benzenediol, 4-methyl-
13	1H-Inden-1-one, 2,3-dihydro-2-methyl-
14	1,3-Benzenediol, 2,5-dimethyl-
15	1-Methylindan-2-one
16	1-Propanone, 1-(2,4-dimethylphenyl)-
17	Benzene, 1-(1-methylethenyl)-3-(1-methylethyl)-
18	1,3-Benzenediol, 2,5-dimethyl-
19	5,8-Dimethyl-1,2,3,4-tetrahydro-1-naphthol
20	Ethanone, 1-(3,4,5-trimethylphenyl)-
21	1,3-Benzenediol, 4,5-dimethyl-
22	7-Methylindan-1-one
23	1,3-Benzenediol, 4,5-dimethyl-
24	7-Methylindan-1-one
25	Naphthalene, 1,2,3,4-tetrahydro-6,7-dimethyl-
26	4-Methoxy-2,6-dimethylphenol
27	1,4-Benzenediol, 2,3,5-trimethyl-
28	3-Isopropyl-1,2-benzenediol
29	1H-Inden-1-one, 2,3-dihydro-7-hydroxy-3-methyl-
30	Phenol, 2-(2-penten-4-yl)-4-methyl-
31	Benzaldehyde, 2,3,4,5-tetramethyl-
32	(S)-1-(4-Methoxyphenyl)-2-methylpropyl acetate

33	Benzofuran, 2,3-dihydro-2,2,5,6-tetramethyl-
34	4-Methoxy-2,6-dimethylphenol
35	1-Naphthalenol
36	(E)-4-(3,4-Dimethoxyphenyl)but-3-en-1-yl acetate
37	1H-Inden-1-ol, 2,3-dihydro-3,3-dimethyl-
38	Benzene, 1,3,5-trimethyl-2-(1-methylethenyl)-
39	1-Hydroxy-1,2,3,4-tetrahydronaphthalene-8-carboxaldehyde
40	4-(Cyclopent-2-en-1-yl)phenol
41	Coumarin, 3,4-dihydro-4,5,7-trimethyl-
42	1-Methyl-2-naphthol
43	7-Methylnaphthalen-2-ol
44	1-Naphthalenol, 2-methyl-
45	Benzene, 1,2,3,4-tetramethyl-4-(1-methylethyl)-
46	1-Naphthol, 6,7-dimethyl-
47	1-Naphthol, 5,7-dimethyl-
48	1-Naphthol, 2,5,8-trimethyl-
49	Azulene, 1,4-dimethyl-7-(1-methylethyl)-
50	2-Methylhexacosane
51	Carbonic acid, decyl heptadecyl ester
52	Hexacosyl nonyl ether
53	2-Methylpentacosane
54	Nonadecyl heptafluorobutyrate
55	Dotriacontyl pentafluoropropionate
56	Tetrapentacontane, 1,54-dibromo-
57	Octatriacontyl trifluoroacetate
58	Tetrapentacontane, 1,54-dibromo-
59	2-Methylhexacosane
60	Hexatriacontane
61	15-Methylnonacosane
62	Tetrapentacontane, 1,54-dibromo-
63	Carbonic acid, octadecyl vinyl ester

40 to 400 °C

1	Ethyl hydrogen oxalate
2	2-Butene, (E)-
3	2-Hexanone, 5-methyl-
4	1,3-Pentadiene
5	1,3-Cyclopentadiene
6	3-Hexene, (E)-
7	1,4-Cyclohexadiene
8	1,3-Cyclopentadiene, 1-methyl-
9	Benzene
10	1,3-Cyclopentadiene, 2-methyl-
11	Toluene
12	Ethylbenzene
13	p-Xylene
14	Styrene
15	Benzene, 1-ethyl-3-methyl-
16	Phosphonic acid, (p-hydroxyphenyl)-
17	Mesitylene
18	Indene
19	Phenol, 2-methyl-
20	2-Methylindene
21	Benzene, 1-methyl-4-(1-propynyl)-
22	Azulene
23	Phenol, 3,4-dimethyl-
24	Naphthalene
25	Phenol, 3,4-dimethyl-
26	Phenol, 3-ethyl-5-methyl-
27	Phenol, 2,3,5-trimethyl-
28	Naphthalene, 2-methyl-
29	Naphthalene, 1,3-dimethyl-
30	Biphenylene
31	Hexatriacontane
32	Tetrapentacontane
33	Hexatriacontane
34	Tetrapentacontane, 1,54-dibromo-
35	Dotriacontyl pentafluoropropionate
36	Tetrapentacontane, 1,54-dibromo-
37	2-Methylhexacosane
38	Tetrapentacontane, 1,54-dibromo-
39	Tetrapentacontane, 1,54-dibromo-
40	Heptacosyl heptafluorobutyrate
41	Tetrapentacontane, 1,54-dibromo-
42	Eicosyl trifluoroacetate
43	11-Methyltricosane
44	Hexatriacontane
45	2-Methylhexacosane

400 to 850 °C

# Next experiments

1. Washing and extracting the remaining Biocrude and Hydrochar from the Reactor and Coolers.
2. Decreasing the Flushing rate (maybe 50/50), to investigate the influence of higher pH and conductivity on the final products
3. Using different solvents for extraction
4. Purging the cHTL process with CO<sub>2</sub>

under revision by the European Commission

**Thanks for your time and  
attention!**